



Installation of Resin-Backed Tile and Stone

TDS 150

In recent years we have seen a large increase in the use of different backing materials for ceramic tile and stone. Cutting the stone thinner allows more stone to be taken from a quarry. Advances in stone cutting and tile setting technology means that traditional methods are no longer required to install tile and stone.

In the old days, tile and stone installations were composed of a mortar bed, a “neat” cement coat, water, and then the tile or stone was beat into the fresh mortar bed. Installations of tile or stone in this manner were labor intensive and expensive, but extremely durable. Stone was cut thicker (and heavier) which led to the additional advantage that gravity provides.

Today, with the increases in stone cutting technology, natural stone can be cut dimensionally into tile that is ¼” (6mm) thick. It is a fact that part of stone’s natural beauty is that each piece is different and may contain many defects or flaws; this adds not only to the beauty of stone, but also to its fragility. To maintain the structural integrity of each piece of stone many manufacturers are applying a backing material to provide added stability and rigidity. Some of these backing types are even showing up on ceramic mosaic tile, glass mosaic tile, and stone mosaic tile. However, these backings can present some real challenges to the installer.

The backing materials widely used throughout the industry include polyester, urethane and epoxy. Some backings can include a fiber mesh imbedded in the resin while others can be a resin with a coarse sand broadcast into it. Ceramic tile and stone backed with the coarse sand impregnated backing may be set with 254 Platinum and relies on the fact that better mechanical adhesion can be achieved.

The type of resin used on the back of the finish material can also influence the adhesive that can or should be used. Another factor that must be taken into account is how well the resin or backing is attached to the tile or stone. Examination and testing should be conducted to determine how well these resins are attached. A simple fact is that, at present, there are no standards that govern the required parameters of the resinous backing to the tile or stone. This leaves the installer in the unfortunate position of trying to determine if the finish material and backing are suitable, and then trying to figure out how to install it. It is ironic that the tile setting materials should meet industry standards but the resin backing materials do not have standards to meet. Therefore, it would stand to reason that the adhesive used would be subject to failure due to the loss of bond of the resin to the tile or stone.

Polyester is the most common backing material being used in the tile and stone industry because it is the most inexpensive type of material. Polyester resins are generally cold applied and are poured or rolled onto the back of the stone. As the polyester hardens it develops a waxy film on the surface which presents a daunting problem for most latex thin-set mortars. Therefore, it is strongly recommended that LATAPOXY® 300 Adhesive be used for these types of backings.

Epoxy resins are of better quality and usually provide excellent adhesion to the back of the stone. But, latex fortified thin-set mortars will have a very hard time bonding to these resins. The epoxy resins are generally a two-part product (resin and hardener) which are cold applied to the back of the stone. LATAPOXY 300 Adhesive is the preferred choice when setting epoxy backed stone.

Urethane backing materials are the least used throughout the industry. LATAPOXY 300 Adhesive is also the adhesive of choice for this type of backing.

NOTE: An option for using resin backed stone in vertical applications is to use the spot bond method. This can be done using LATAPOXY 310 Stone Adhesive or LATAPOXY 310 Rapid Stone Adhesive placed in a minimum of five spots on the back of the stone and should cover a minimum of 10% of the area. The resin must first be grinded off the back, exposing bare stone, and then cleaned prior to applying the LATAPOXY 310 Stone Adhesive.

Some of the old rules apply even to large format, resin backed tile or stone. Moisture sensitive stone (e.g. green marble) must still be set with LATAPOXY® 300 Adhesive no matter what type of resin is used on the back. White or light colored stone should still be set using a white mortar, and some installers will only use a white mortar when setting any stone product to avoid any confusion at the job site. Movement joints must be honored at the perimeter of the installation as well as in the field. The recommendation is to follow the Tile Council of North America (TCNA) Handbook guidelines outlined in EJ-171 and use LATASIL™ for movement joint applications. Some porous stone may require LATASIL 9118 Primer.

For more information on the installation of resin-backed glass mosaic tile please refer to LATICRETE TDS 145 “Installation of Glass Mosaic Tile” available at www.laticrete.com.

Technical Data Sheets are subject to change without notice. For latest revision, check our website at www.laticrete.com
TDS 150.doc R 15 August 2013



LATICRETE INTERNATIONAL, INC. ▪ 1 LATICRETE Park North ▪ Bethany, CT 06524-3423 USA
800.243.4788 ▪ support@laticrete.com ▪ www.laticrete.com

©2013 LATICRETE INTERNATIONAL, INC. All trademarks shown are the intellectual properties of their respective owners.